


MICROWAVE OVEN ELECTROLUX

DO NOT PLACE METAL DISHES OR ALUMINUM FOIL IN THE MICROWAVE OVEN!

Control panel



Use

1. Select the desired power with the **Power** buttons.
2. Press the **Add/Reduce** buttons to set the time.
3. Press the **Start** button.

Quick start

You can start cooking quickly in 800 W/HIGH mode for 30 seconds by pressing the Start button. To increase the cooking time during cooking, press the Start button. One press increases the cooking time by 30 seconds.

Things to note

After cooking the turntable continues to rotate until the cookware returns to its original position. The oven beeps when cooking is complete.

If the oven is used in any mode for at least 3 minutes, the fan will remain on for 2 minutes after cooking is complete. If you open the door, the fan will turn off and when you close the door, it will restart until it is full for 2 minutes.

Power

800 W: Used for instant cooking or heating soups, casseroles, canned food, hot drinks, vegetables, fish, etc.

560 W: Used for longer cooking. Roasts, meatloaf, ready meals, cheese sauce and sugar cakes.

400 W: Used for foods that take long time to cook with traditional methods (e.g. beef).

240 W/DEFROST: Used for defrosting food. Also suitable for slowly cooking rice and pasta.

80 W: Used for careful defrosting, e.g. stuffed cakes or pastries.

Favorites



Softening butter. Put the butter (0,05-0,25 kg) in a plastic bowl. Stir well after softing.



Melting chocolate. Chop the chocolate (100-200 g) and put it in a plastic bowl. Stir when you hear a beep. Stir well after melting.



Mug cake. Prepare the cake according to the recipe. Place the mug (1-4) on the edge of the turntable. Let stand for 30 seconds after cooking.