


MICROWAVE BOSCH

DO NOT PLACE METAL DISHES OR ALUMINUM FOIL IN THE MICROWAVE

CONTROL PANEL




1	Display	Display clock or cooking time.
2	Rotary selector	Set the time, cooking time or automatic programmes.
3	Buttons	Select functions.
4	Door opener	Open the door.

USE

1. Press the button for the microwave setting that you require.
2. Use the rotary selector to set the requires cooking time.
3. Press Start button.
4. An audible signal sounds once the cooking time has elapsed.

USING THE PROGRAMS

1. Select a program.
2. Press  repeatedly until the display shows the required program number.
3. Press kg → the display shows a default wight.
4. Turn the rotary selector to specify the weight of the dish.
5. To start operation, press Start button.
6. If a signal sound during the program, open the appliance door and stir or turn the food. Close the appliance door and press Start button.
7. An audible signal sounds once the cooking time has elapsed.

If you want to stop the operation before it runs out, open the appliance door and press Stop selector.

QUICK START

You can use a button to start the maximum microwave power setting.

1. Press Start button.
2. The maximum microwave power setting is started for 30 seconds.
3. Press Start button again to extend the cooking time by 30 seconds in each case.

MICROWAVE POWER SETTINGS

Microwave power setting In watts	Use
90	Defrost delicate foods.
180	Defrost food and continue cooking.
360	Cooking meat and fish or heating delicate foods.
600	Heat and cook food.
800	Heat liquids.

AUTOMATIC PROGRAMS

DEFROSTING

Programme	Food	Cookware	Weight range In kg
P01	Minced meat	Open	0.20–1.00
P02	Pieces of meat	Open	0.20–1.00
P03	Chicken, chicken pieces	Open	0.40–1.80
P04	Bread	Open	0.20–1.00

COOKING

Programme	Food	Cookware	Weight range In kg	Information
P05	Rice	With lid	0.05–0.20	<ul style="list-style-type: none">■ For rice, use a large, deep dish.■ Do not use any boil-in-the-bag rice.■ For every 100 g rice, add twice to three times the amount of water.
P06	Potatoes	With lid	0.15–1.00	<ul style="list-style-type: none">■ For boiled potatoes, cut fresh potatoes into small, equally sized pieces.■ Add one tablespoon of water and a little salt for every 100 g boiled potatoes.
P07	Vegetables	With lid	0.15–1.00	<ul style="list-style-type: none">■ Weigh fresh, washed vegetables scales.■ Cut the vegetables into small, uniform pieces.■ Add one tablespoon of water for every 100 g boiled potatoes.

CHILDPROOF LOCK

You can secure your appliance to prevent children from accidentally switching it on or changing the setting.

- ➔ Press and hold Stop button for approx. 4 seconds. The control panel is locked and SAFE appears in the display.
- ➔ To deactivate the childproof lock press and hold the Stop button for approx. 4 seconds. The control panel is unlocked.