Jacuzzi instructions

Before you go in to the jacuzzi

- ➤ lift the deck
- wash yourself carefully
- take the floating chlorine dispenser out of the jacuzzi

After using the jacuzzi

- put the floating chlorine dispenser back to the jacuzzi
- > put the deck back

JACUZZI FUNCTION:



"Massage" To activate massage programme, push this button once. If you want higher level, push second time and if you want to end program push third time. Massage ends automatically after 4 hours in lower level and in higher level after 15 minutes. NOTICE! If no water is coming from jets, please turn the jets



"Temp" Water temperature has been set in 36°C, which is the recommendable temperature. Last measured temperature can be seen in the LCD monitor.



"Light" Push this button once to get lights in the jacuzzi. To turn off the lights, push button second time. Lights will turn off automatically after 4 hours.

NOTICE: Pushing more than one button at the same time might change the programmed settings and water in the jacuzzi gets cold.

OTHER NOTICES:

- Recommended number of persons in the jacuzzi at the same time is maximum 4-5persons.
- > Bringing drinks and food to jacuzzi is strictly forbidden.
- The water temperature has been set in 36°C. Check the temperature always before entering to the jacuzzi. Recommended duration of stay in the jacuzzi is max 15 minutes. Longer term stay at high temperatures may be a threat to your health. Avoid long exposure to hot water.
- Persons who have the following health conditions should discuss with the doctor before using the jacuzzi: diabetes, too low or too high blood pressure, heart disease, overweight, vascular disease, pregnancy, medication or infectious diseases.
- ➤ We maintain jacuzzi regularly to make sure the water quality is good. By arrival the temperature of jacuzzi may not have risen yet to the set temperature due to cold water added during the maintenance. The temperature rises ca.+1°C/hour. Maintenance can cause temporary break for using jacuzzi, which is not a reason for reclamation.
- Make sure there is enough water in the jacuzzi. If the water level is too low (below the filter), jacuzzi goes off automatically. Please, add more water with a bucket you can find from the bathroom or from the balcony (next to the jacuzzi).
- Customer is responsible that jacuzzi is in normal condition when reservation ends. If the customer's irresponsible behaviour causes any damage to the jacuzzi, Ski-Inn Hotels & Apartments Ltd will charge the costs from the customer (min 300€). If the jacuzzi is in untidy condition, Ski-Inn Hotels & Apartments Ltd will charge the costs of disinfectant cleaning (minimum €120) from the customer. Cost for the lost chlorine dispenser is 50€.
- ➤ Cost of changing the water during your holiday is minimum 150€. You can order the water change from Hotel Pyhätunturi reception.
- > Ski-Inn Hotels & Apartments Ltd is not responsible for any inconvenience caused to the customer by their irregular actions.
- If you have any problems, please contact Hotel Pyhätunturi reception.