


## Fireplace instructions


1. Pull out the chimney cover and set the air ventilation of the cooker hood to the minimum.
2. Turn on the fireplace switch.
3. Adjust the combustion air control in the ash box under the fireplace door.
4. Start with a small amount of firewood. If necessary, open one of the windows a little bit.
5. Keep the fireplace glass door closed while the fire is burning.
6. Do not close the chimney cover until the embers are completely extinguished and grey. Leave the cover slightly open afterwards.
7. **Do not handle the ashes. Ash removal is carried out by staff only. Please contact reception: +358 (0) 10 382 515.**

### Please see detailed instructions below:

1. Pull out chimney cover on the top of a fireplace.




2. Set the air conditioning to minimum in the cooker hood.



3. Turn on the fireplace switch.





4. Adjust combustion air control in the ash box under fireplace door.
5. Start with a small amount of wood. You can also use Firestarter when you set a fire.

