



CERAMIC HOB

DESCRIPTION

1. Dual cooking zone
2. Single cooking zone
3. Control panel



CONTROL PANEL



1. Power switch
2. Temperature adjustment button
3. Automatic maximum
4. Dual cooking zone
5. Time control
6. Minute clock
7. Child safety lock
8. Cooking zone power display
9. Time display

USE

1. Press power switch (1).
2. Press – and + temperature adjustment buttons (2) to adjust the selected cooking zone to desired power. The cooking zones must be adjusted within 10 seconds or they will switch off.
3. To deactivate the cooking zone, press the – and + buttons (2) simultaneously until "0" is displayed.
4. Press the power switch to switch off all cooking zones.

USE OF THE DUAL COOKING ZONE

1. Press power switch (1).
2. Press the double cooking zone button (4) to switch on the double cooking zone.
3. Press the – and + buttons (2) to adjust the cooking zone power.
4. To deactivate the double cooking zone, press the double cooking zone button (4).

Both cooking zones have an after-heat indicator light. When the cooking zone is switched off, the display shows "H" until the cooking zone has cooled down. "H" means that the cooking zone is still hot.

ADDITIONAL FUNCTIONS

Automatic maximum

Using this function, there is no need to reduce the power during cooking. The function switches the maximum possible temperature to the cooking zone for a specified time and then automatically adjusts it to the temperature you have selected. The function is selected as follows:

1. Switch on the cooking zone by pressing the power switch (1).
2. Set the cooking zone to the temperature at which you want to cook the food.
3. Press the A button (3).

After selecting this function, the "A" indicator appear on the control panel. To deactivate the function, press the button A (3). The table below shows the recommended adjustment positions when using the automatic maximum function.

Power	Process	Examples
1	Keeping food warm	Pienten annosten lämpimänä pitäminen
2	Melting	Gelatin, chocolate, butter
3-4	Heating	Sauces
4	Slowly boiling	Rice, dairy foods
5-6	Boiling	Soup
6-7	Boiling	Potatoes and vegetables
7	Browning	Liver, sausages, steaks
7-8	Browning, frying	Egg, chops, meatballs
8	Browning	Pancakes, french fries, steaks

Safety cut-out

If one of the buttons is activated for more than 10 seconds, the cooking zone switches off automatically.

Automatic shut-off

If you forget to turn off one or more cooking zones, the power will turn off automatically after a set time. The elapsed time depends on the selected power and is shown in the table below. When the auto power off occurs, the power light blinks. Press the power button and the auto power off light will reset.

Power	Maximum time before automatic shut-off
1-2	6
3-4	5
5	4
6-9	1,5

Child safety lock

The lock allows you to prevent a child or anyone else from accidentally switching on the cooking zones. When the child safety switch is on, the power button and minute clock can be used. To use this feature:

1. Press the on / off button to switch on the cooking zone.
2. Press the child lock button (7) for 3 seconds

The child lock indicator light comes on.

If an attempt is made to activate the cooking zone while the child lock is operating, the power and child lock indicators will light up. Press the power button again and they will turn off.

To turn off the feature:

1. Press the power button.
2. Press the child lock button for 3 seconds.

The child safety lock indicator light goes out.